




Scan the code
to watch the video

deconovo
your home decor specialists



Motorized Roller Shade User Manual

| Standard Motor



CONTENTS

01

Remote control pairing

Features, application & operation instructions

03

Delete All Pairings(Method A & Method B)

04

02


How to install on the wall?

Preparation, accessories & inside mount

05

Outside mount(Installation steps)


06



Remote control pairing


I .Features

- 1、Energy Saving Patent.
- 2、Built-in Rechargeable Lithium Battery Pack.
- 3、It has automatic correction function for the displacement generated by braking.
- 4、The built-in control parts of motor are sealed well for bettesafety
- 5、It's easy to switch the mode between inching and interlockand control operation direction.
- 6、Electronic limits setting,6 limits can be set (2 end limits and 4 middlelimits).
- 7、Short circuit protection & open circuit protection for sensor.
- 8、Built-in low power Bluetooth module and APP intelligent controfunction.



II .Application

It can be fully charged within 4 hours,Please unplug the charger when fully charged.



! CAUTION!

Please charge lithium battery devices at least 6h every 6 months to extend battery life.

III.Operation Instruction

1.Power ON



Slide the switch to "I"
to turn on the motor



Press the Pairing
button for 1 second
then release it. The
motor will jog once



Press the UP button on the remote
The motor will jog again to confirm
the pairing is complete

2.Programming Preparation

*If there is no action in 10 seconds, the motor will exit programming automatically



1、 To set the upper limit, first open the battery cover on the back of the remote and locate the small programming button.

2、 Move the roller shade to the desired position. Press the round button on the back of the remote, then press the UP button, and press the round button again. The motor will jog to confirm the upper limit is set.

3、 To enable jog mode,press and hold thestop button for 5seconds. The motorwill jog once. Then press the stop button once. The motor will jog again to confirm jog mode is enabled.

3.Delete All Pairings

*Method A



First, press the pairing button twice with short presses (about 1 second each), then press and hold the pairing button twice (about 5 seconds each). The motor will jog twice, indicating that all remote control pairings have been successfully deleted. After unpairing, the remote control will no longer operate the roller shade.

*Method B




First, press and hold the middle button on the remote control for 5 seconds until the motor jogs once. Then press and hold the button on the back of the remote control for 7 seconds. The motor will jog twice, indicating that all remote control pairings have been successfully deleted.


How to install on the wall?

i *Your blind has been programmed before shipment. Please use it directly

1. PREPARATION




* Punch Diameter 0.2" (6mm)



2. ACCESSORIES



V



b xn




f xn


3. SHADES INSTALLATION (WITH VALANCE)

1. INSIDE MOUNT


01.



03.




02.




2. OUTSIDE MOUNT


01.



02.



03.



04.

